







Ref No.	Description	Part No.	Ref No.	Description	Part No.
1	FAN GUARD	9378498006	72	COIL	9709058008
2	BELL MOUTH	9379709002	100	ACCUMULATOR ASSY	9379221023
3	RIGHT PANEL ASSY	9378920002	101	OIL SEPARATOR ASSY	9379677011
4	LEFT PANEL ASSY	9378919006	102	COMPRESSOR(INV) ASSY	9380804000
5	SIDE PILLER ASSY	9379202008	103	COMP BOLT	9378474017
6	REAR PILLER	9378472006	104	WASHER(RUBBER)I	9379179003
7	MAIN PILLER	9378468009	105	CLAMP 19	9379459006
8	NET RIGHT ASSY	9378927001	106	JNT PIPE(SUB COOL HEX)A	9374381036
9	NET LEFT ASSY	9378928008	107	VALVE(4-WAY)A ASSY	9379052030
10	CONDUIT PLATE	9378493018	108	VALVE(4-WAY)B ASSY	9379052047
11	PROPELLER FAN	9378488007	109	BYPASS VALVE A ASSY	9378744127
12	MOTOR,DC BRUSHLESS	9603212018	110	UNION JOINT	9970091018
13	MOTOR BRKT ASSY	9378925014	111	SOLENOID 4WV A	9970113031
14	LABEL(FUJITSU)	9380477006	112	SOLENOID 4WV B	9970113048
	LABEL(GENERAL)	9378949003	113	OIL RETURN VALVE A ASSY	9378745032
15	LABEL(AIRSTAGE)	9380479000	114	DISCHARGE PIPE A ASSY	9378888036
16	TOP PANEL L	9378491007	115	SUCTION PIPE A ASSY	9378741065
17	REAR PANEL L ASSY	9378921023	116	OIL RETURN VALVE B ASSY	9378747128
18	NET REAR L ASSY	9378926004	117	SOLENOID SV1	9970044052
19	BASE FOOT RL ASSY	9378856028	118	SOLENOID SV2	9900189198
20	BASE FOOT FL ASSY	9378856004	119	SOLENOID SV3	9900189204
21	FRONT PANEL L	9378480001	120	SOLENOID SV4	9970126000
22	S PANEL TOP L	9380231004	121	COIL(EXPANSION VALVE 1)	9970114014
23	S PANEL BTM L	9380232001	122	COIL(EXPANSION VALVE 2)	9970114021
24	CONDENSER L ASSY	9379053037	123	COIL(EXPANSION VALVE 3)	9970101076
25	ACCESSORY PIPE A	9379200028	124	LOW PRESSURE SENSOR	9900505035
26	ACCESSORY PIPE B	9379200004	125	HIGH PRESSURE SENSOR	9900505028
27	ACCESSORY PIPE C	9379200042	126	PRESSURE SW (INV COMP)	9900504038
	(Except AJT108)		127	3WAY VALVE ASSY(Suction gas pipe)	9379039048
27	ACCESSORY PIPE C (AJT108)	9379200066	128	3WAY VALVE ASSY(Liquid pipe)	9379039031
28	ACCESSORY PIPE D	9379200059	129	3WAY VALVE ASSY(Discharge gas pipe)	9379039055
50	HEAT SINK F	9378511057	130	SUB COOL HEX ASSY	9378749061
51	HEAT SINK C	9378511026	131	EXPANSION VALVE ASSY	9378750067
52	THERMO HOLDER	9378510005	132	JOINT PIPE OILSEPARATOR A ASSY	9378737099
53	MAIN PCB ASSY	9709270141	133	SUCTION PIPE C ASSY	9378742062
54	INVERTER PCB ASSY	9709914199	134	JOINT PIPE A ASSY	9378739024
55-1	FILTER PCB(INV) ASSY PRIMARY	9709920008	135	2-WAY VALVE ASSY	9365504079
55-2	FILTER PCB(INV) ASSY SECONDARY	9709921005	136	JOINT PIPE(OIL SEP)	9379693035
56	FILTER PCB(MAIN) ASSY	9709918005	137	RECEIVER TANK ASSY	9380825005
57	FAN DRIVER PCB ASSY	9709916001	138	CRANK CASE HEATER 1 (INV COMP)	9901063022
58	TERMINAL	9900251031	139	CRANK CASE HEATER 2 (INV COMP)	9901063015
59	MAGNETIC RELAY	9900566005	140	CLAMP 31 SA	9379432009
60	REACTOR ASSY	9900744007	-	THERMISTOR (TH8,10) ASSY	9900752002
61	CAPACITOR	9709615010	-	THERMISTOR (TH3) ASSY	9900753009
62	RESISTOR,CEMENT	0200441016	-	THERMISTOR (TH1,11) ASSY	9900884000
63	RESISTOR,CEMENT	0200444017	-	THERMISTOR (TH4,5,6) ASSY	9900750008
64	OUTDOOR TEMP THERMISTOR(TH2)	9900747008	-	THERMISTOR (TH7,9) ASSY	9900751005
65	COMMUNICATION PCB	9707774023	-	EMI FILTER	0400434016
66	DIODE BRIDGE	0001113013	-	WIRE(INV COMP)B	9378456037
67	HEATSINK THERMISTOR	9900518004			
69	HEAT SINK K	9378511095			
70	PHASE CT PCB	9708938011			
71	TERMINAL	9900428112			

	Description
TH 1	Discharge temp. thermistor 1
TH 3	Suction temp. thermistor
TH 4	Sub-cool heat ex.(inlet liquid) thermistor
TH 5	Sub-cool heat ex.(outlet liquid) thermistor
TH 6	Sub-cool heat ex.(outlet gas) thermistor

	Description
TH 7	Heat ex. 1 (gas) thermistor
TH 8	Heat ex. 2 (gas) thermistor
TH 9	Heat ex. 1 (liquid) thermistor
TH10	Heat ex. 2 (liquid) thermistor
TH11	Compressor shell temp. thermistor